



Compare the air temperature with the relative humidity to figure out how well your evaporative cooler will work

Temperatures Delivered by Evaporative Coolers
% Relative Humidity

	2	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
75	54	55	57	58	59	61	62	63	64	65	66	67	68	69	70	71	72
80	57	58	60	62	63	64	66	67	68	69	71	72	73	74	76	76	77
85	61	62	63	65	67	68	70	71	72	73	74	75	76	77	79	81	
90	64	65	67	69	70	72	74	76	77	78	79	81	82	83	84	86	
95	67	68	70	72	74	76	78	79	81	82	84	85	87				
100	69	71	73	76	78	80	82	83	85	87	88						
105	72	74	77	79	81	84	86	88	89								
110	75	77	80	83	85	87	90	92									
115	78	80	83	86	89	91	94										
120	81	83	86	90	93	95											
125	83	86	90	93	96												

Optimum conditions for Evaporative Coolers

Source: Ed Phillips, Arizona Almanac

Example: If it's 95°F outside and the humidity is 15%, your evap cooler should put out air that is 72°F. Anything cooler than the grey boxes should be comfortable, warmer will probably be uncomfortable.